

S9-50 : Use of PLL IC 145162 In Place Of 8805

When using PLL IC 145162 in PCB where 8805 is originally used, the following modification has to be carried out.

- (1) Cut trace connected to the solder pad of Pin-8 of IC5.
- (2) Connect Pin-7 of IC5 to the trace originally connected to Pin-8 of IC5.

Please refer to the illustration below.

