

This Manual is provided by
CBTricks.com

Someone who wanted to help you repair your equipment put together this information.

Royce 1-641 Alignment Instruction

If you would like to help us put more manuals online support us.

If you would like to help with this project let us know.

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

If your company would like to provide technical information to be featured on this site I will put up on the site as long as I can do it in a non-commercial way.

The site is supported with donation from users, friends and selling of the Galaxy Service Manual CD to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

ALL the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). This work was not done for someone else to make money also, for example the ebay CD sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners.

This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers.

Thank you for any support you can give.

I-641 ALIGNMENT INSTRUCTION

RECEIVER

1. Testing Equipment to be used:

* Power Supply 13.8VDC	1 set
* Standard Signal Generator	1 set
* Low Frequency Voltmeter	1 set
* Oscilloscope	1 set
* 8 ohms Dummy Load	1 pc.
* Speaker	1 pc.
* Microphone	1 pc.

2. Alignment Procedures:

- 1) Set the Mode Switch to AM, Volume Control at maximum, Squelch at minimum, Clarifier in the center and the CB-PA Switch to CB.
- 2) Set the SSG on Channel 19 and Channel Selector of the unit on Channel 19. Then, connect the Power Supply and 8 ohms Dummy Load to the transceiver unit.
- 3) Feed the signal from the SSG and set the audio output for a peak reading by adjusting T-1, T-2, T-3, and T-10.
In this case be sure that antenna input should be less than $1\mu\text{V}$ at the AF standard output power. Also, make sure that the audio on the oscilloscope is a sine wave.
- 4) Set the antenna input at $1\mu\text{V}$ so that the antenna power may be more than 0.5 Watt at the maximum volume of all channels.
- 5) Set the antenna input at $1,000\mu\text{V}$ so that the output power should be more than 3.5 watts at the maximum volume.
- 6) Set the antenna input to $50,000\mu\text{V}$ and the low frequency output to 0.5 watt by volume control. Then, decrease the antenna input until the low frequency output stays 10 dB lower. Be sure that the antenna input then should be less than $5\mu\text{V}$.
- 7) Set the antenna input to $100\mu\text{V}$ and the meter indication to 9 by VR4.
- 8) Set the volume control and squelch control at maximum, and set the tight squelch by VR2 so that the output from speaker is heard when the antenna input is increased upto $500\mu\text{V}$.
- 9) Set the antenna input to $0.7\mu\text{V}$ and be sure that the low frequency output should be over 10 dB more when the modulation of the SSG is turned off at the normal output.
- 10) Set the Mode Switch to USB, Volume Control at maximum, Squelch at minimum and Clarifier in the center. Tune off the modulation of the SSG and remove the frequency by 1 KHz.
- 11) Make sure that the maximum sensitivity should be less than $0.2\mu\text{V}$.
- 12) Make sure of AGC like with AM.
- 13) Set the antenna input to $0.15\mu\text{V}$ and keep the AF output to be over 10 dB lower when the antenna input is turned off at the normal output.

3. PA Functioning:

- 1) Set the PA-CB Switch to PA. Connect the dummy load to PA Speaker Jack and microphone to Microphone Jack.
- 2) Make sure of the variation of the sound level with the volume control by pushing down the push-to-talk knob on the microphone.

4. Receiver Alignment Specifications:

AM:	Maximum Sensitivity	less than 1 μ V
	Low Frequency Output	more than 3.5 Watts
	AGC	more than 80 dB
	Meter	S9 at 100 μ V
	SQ	500 μ V
	S+N/N	more than 10 dB at 0.7 μ V
SSB:	Maximum Sensitivity	less than 0.2 μ V
	AGC	more than 80 dB
	Meter	S9 at 100 μ V
	S+N/N	more than 10 dB at 0.15 μ V

TRANSMITTER

1. Connection of test equipment.
 - * Power supply at 13.8 VDC.
 - * Connect a Power meter, oscilloscope frequency counter, spectrum analyzer and P-P RF volt meter to the RF output connector.
 - * Connect an AF oscillator and AF volt meter to the microphone connector.
2. Power adjustment.
 - * Set the mode switch to AM.
 - * Adjust T7, 6, 11, 12, 13, 14, and T15 for the maximum point.
 - * Adjust L6 for 3.6 W output.
 - * Adjust L1 to increase 2nd harmonic.
3. Frequency-Make sure every channel stays within ± 800 Hz.
4. Modulation Limiter Adjustment.
 - * Put in 1KHz and 500mV signal from AF oscillator and adjust VR7 for 90% modulation.
5. Modulation capability.
 - * Put in 1KHz signal by AF oscillator and get 90% modulation for the minus side. The plus side should be over 80%.
6. SSB.
 - * Set the mode switch to USB.
 - * Put in two-tone signal of 1KHz and 1.6KHz by two AF oscillators.
7. ALC alignment.
 - * Adjust the two-tone signal of AF oscillator for 3 W RF power output.
 - * Adjust VR8 for 11W PEP RF power output when the two-tone signal is increased by 20 dB.
8. Carrier suppression.
 - * Cut off the two-tone signal and make sure the output level of the carrier is below -40 dB.
 - * Set the mode switch to LSB and do the same.

Regulated power supply

1. Connect the output cord at the terminal 1 of regulated power supply to the minus (-) terminal of voltmeter, and that at the terminal 2 to the plus (+) of it. Set AC/DC switch in AC position and supply 117 volts to the power supply unit. Then, turn on the power switch.
2. Adjust VR9 in power supply to read 13.8 volts on the voltmeter.