



29 LTD BT

Bluetooth Operation

To pair the CB to your cell phone

Press and HOLD the Bluetooth button on the microphone until you hear a beep. The Bluetooth light on the CB should be blinking on and off.

You now have 5 minutes to link with the cell phone. You will need to push buttons on your cell phone to complete the pairing process. If you are not sure how to setup a Bluetooth device on your cell phone, then refer to the owners manual or contact your cell provider.

During the pairing process you will need to enter a passcode. The passcode is 0000.

After successfully pairing, the Bluetooth light on the CB will blink every 10 seconds to indicate Bluetooth standby mode. After 1 minute it will stop blinking (so as not to annoy you).

To answer a call

Press and release the Bluetooth button on the microphone. The Bluetooth light on the CB should remain steady.

Conduct your conversation. It is not necessary to press any buttons.

All CB functions will be disabled during the call.

To end the call, press and release the Bluetooth button on the microphone.

NOTE: There is a separate microphone in the handset for the Bluetooth function. It is behind a small hole on the microphone, in the lower-right. Do not block this hole!



To initiate a call

Dial out from the cell phone, then set the phone aside.

You should hear the dialing and ring sounds from the speaker on the CB.

During the call the Bluetooth light on the CB should remain steady.

To end the call, press and release the Bluetooth button on the microphone.

Voice dialing

This feature only works if your phone has voice dialing.

Press the Bluetooth button on the microphone 2 times. You must do it quickly.

Speak into the microphone.

If it identifies a number to call, you will hear the voice identifier through the CB speaker.

If the call does not go through then most likely it did not recognize your voice. Try again.

During the call the Bluetooth light on the CB should remain steady.

To end the call, press and release the Bluetooth button on the microphone.

To redial a call

Press and HOLD the Bluetooth button on the microphone for a couple of seconds until you hear a beep. The cell phone should automatically redial the last number called.

During the call the Bluetooth light on the CB should remain steady.

To end the call, press and release the Bluetooth button on the microphone.

To disable the Bluetooth link

Press and HOLD the Bluetooth button on the microphone until you hear a double-beep. You may hear 1 or 2 single beeps, just keep holding the button until you hear a double-beep. The Bluetooth light on the CB should remain dark.

To re-enable the Bluetooth link

Press and HOLD the Bluetooth button on the microphone until you hear a single beep. The Bluetooth light on the CB should blink every 10 seconds.

IMPORTANT NOTE

You must keep your cell phone in a location where it gets good reception from the cell tower.